

INSTALLATION INSTRUCTIONS

MODEL NO. 65130

APPLICATION: 2000-03 Chrysler Voyager Van
 2001-03 Chrysler Grand Voyager Van
 1996-05 Chrysler Town & Country Van

1996-04 Dodge Caravan
 1996-05 Dodge Grand Caravan
 1996-99 Plymouth VoyagerVan

WARNING

Although this hitch is designed to safely tow its rated load, we recommend that you consult your vehicle owner's manual for possible manufacturer's recommendations or limitations. Always follow the manufacturer's installation instructions and always install on the specified vehicle. Before installing hitch, check that the attachment points are in good condition.

Failure to follow these guidelines will void warranty. Any modifications to this hitch will void warranty.

WEIGHT CARRYING HITCH CAPACITY


**3500 LBS. MAXIMUM TRAILER WEIGHT
 350 LBS. MAXIMUM TONGUE WEIGHT**

Trailer brakes are recommended for towing loads in excess of 1500 lbs.

COMPLETE PARTS LIST

Part	Description	Quantity
1.	Hitch Assembly	(1)
2.	1861-03 7/16-14 Hex Nut	(2)
3.	2794-08 Square Hole Plate	(2)
4.	1887-03 7/16 Flat Washer	(2)
5.	1879-03 7/16 Lockwasher	(2)
6.	2793-01 7/16-14 x 1-1/2 Carriage Bolt	(2)
7.	2372-04 12mm x 1.75 x 40mm Hex Bolt	(2)

Part	Description	Quantity
8.	1880-03 1/2 Lockwasher	(2)
9.	3899-04 Reinforcement Plate	(2)
10.	4762-01 7/16 Pull Wire	(1)
11.	1083-04 Hitch Pin	(1)
12.	1335-03 Hair Pin	(1)
13.	1076-05 Ball Mount	(1)
14.	4751-04 Receiver Cover	(1)



1. Remove the rear most existing bolt from the bottom of each vehicle side frame. Save these bolts for later hitch installation.
2. Position the hitch assembly up against the bottom of the vehicle frame, in line with the holes where bolts were previously removed. Bolt loosely in place at rear existing weldnuts using bolts removed in Step 1.
3. Assemble a 7/16" carriage bolt #6 with a square hole plate #3 and a pull wire. Insert assembly into access hole in vehicle frame. The access hole must be enlarged slightly for ease of installation. Using the pull wire, position bolt so that it drops out of frame through the small attachment hole located forward of the access hole. If hole is not in frame at that location, a 1/2" hole must be drilled using hole in hitch frame brackets as guide. Bolt hitch in place as illustrated.
4. Remove the center existing bolt from each vehicle side frame. These bolts will be centered within the large hole in each hitch frame bracket.
5. Place a reinforcement plate #9 over the large hole in each hitch frame bracket and bolt in place with the longer 12mm bolts #7 and 1/2" lock washers #8 supplied in kit.
6. Tighten the 12mm bolts to 75 ft. lbs. torque and the 7/16" bolts to 55 ft. lbs. torque. Failure to tighten bolts as described may result in fastener loss or failure.
7. Slide ball mount #13 into hitch assembly receiver and secure with hitch pin #11 and hair pin #12.

WARNING: Use only the ball mount supplied with this hitch. Use this hitch only as a weight carrying hitch.


DO NOT use with any type of weight distributing hitch.

WARNING: If this hitch is used with any auxiliary load carrying product, such as bicycle or cargo carriers, the loaded weight must not exceed 200 lbs. including the weight of the carrier. The loaded carrier weight with the extended leverage may damage hitch and/or attachment points on vehicle.

WARNING: Be sure to check the hitch pin and hair pin for positive locking placement before towing trailer.

NOTE: When hitch is not being used, remove the ball mount from receiver and place receiver cover into receiver opening.

NOTE: Some states require a clear view of license plates. Remove trailer ball and/or ball mount when not in use if it restricts view.



For information regarding this product, or our warranty, contact your dealer or write to:
 "CUSTOMER SERVICE MANAGER" P.O. Box 850, Lodi, CA 95241

This product complies with regulation V-5, C.S.A Standard D-264 and safety requirements for connecting devices and towing systems of the State of New York

65130