

INSTALLATION INSTRUCTIONS

Rev. 1

MODEL NO. 74090 78128

APPLICATION: **1995-99 Chevrolet Tahoe & Suburban**
 1992-94 Chevrolet Blazer
 1992-99 GMC Yukon & Suburban

WARNING: Although this hitch is designed to safely tow its rated load, we recommend that you consult your vehicle owner's manual for possible manufacturer's recommendations or limitations. Trailer brakes are recommended for towing loads in excess of 1500 lbs. Always follow the manufacturer's installation instructions and always install on the specified vehicle. Before installing hitch, check that the attachment points are in good condition.

Failure to follow these guidelines will void warranty. Any modifications to this hitch will void warranty.

WARNING: Use only a 5/8" diameter hitch pin with locking device to secure a ball mount in this receiver. Be sure to check the hitch pin and hair pin for positive locking placement before towing trailer.



NOTE: Some states require a clear view of license plates. Remove trailer ball and/or ball mount when not in use if it restricts view.

COMPLETE PARTS LIST			
Item	Part #	Description	Quantity
1.		Receiver Assembly	1
2.	2835-08	Reinforcement Plate	6
3.	1862-03	1/2-13 Hex Nut	6
4.	3730-05	1/2 Conical Washer	6
5.	1786-03	1/2-13 x 1-3/4 Carriage Bolt Gr. 5	6
6.	4892-07	Pull Wire	1

CLASS V

WEIGHT CARRYING HITCH CAPACITY
 6,000 LBS. MAXIMUM TRAILER WEIGHT
 600 LBS. MAXIMUM TONGUE WEIGHT

WEIGHT DISTRIBUTING HITCH CAPACITY
 10,000 LBS. MAXIMUM TRAILER WEIGHT
 1000 LBS. MAXIMUM TONGUE WEIGHT



1. Place a square hole spacer #2 on each of the 1/2" carriage bolts. Insert one of these assemblies into the end of each vehicle frame and drop bolt down through the existing hole in the bottom of the frame.
2. It will be necessary to use a pullwire to insert the two forward bolt assemblies into the vehicle frame. Position bolts and square hole plates into attachment points through open section of frame forward of the spring shackle attachment point. Access to these points can also be gained from rear of frame before hitch is put up in place. See the pullwire illustration below. Be sure that all three attachment bolts are protruding through the frame on each side of vehicle.
3. Carefully raise the hitch assembly #1 up against the bottom of the vehicle frame so that the previously installed bolts drop down through their corresponding slots in the hitch frame brackets. Secure hitch in place as illustrated.
4. Tighten all 1/2" bolts to 75 ft. lbs. torque. Failure to tighten bolts as described may result in fastener loss or failure.

For information regarding the installation of this product, go to: www.towingsupport.com
 or Email us at: tech@towingsupport.com or Call our Technical Support Team at: 1-800-344-3230

This product complies with regulation V-5, C.S.A Standard D-264 and safety requirements for connecting devices and towing systems of the State of New York