

INSTALLATION INSTRUCTIONS

Rev. 1

MODEL NO. 74470

75123

APPLICATION: 1983-94 Chevrolet S-Blazer 2dr. 1991-94 Chevrolet S-Blazer 4dr.
 1983-94 GMC S-Jimmy 2dr. and 4 Dr.
 1991-94 Oldsmobile Bravada


WARNING: Although this hitch is designed to safely tow its rated load, we recommend that you consult your vehicle owner's manual for possible manufacturer's recommendations or limitations. Trailer brakes are recommended for towing loads in excess of 1500 lbs. Always follow the manufacturer's installation instructions and always install on the specified vehicle. Before installing hitch, check that the attachment points are in good condition. Failure to follow these guidelines will void warranty. Any modifications to this hitch will void warranty.

WARNING: Use only a 5/8" diameter hitch pin with locking device to secure a ball mount in this receiver. Be sure to check the hitch pin and hair pin for positive locking placement before towing trailer.


NOTE: Some states require a clear view of license plates. Remove trailer ball and/or ball mount when not in use if it restricts view.

COMPLETE PARTS LIST			
Item	Part #	Description	Quantity
1.		Receiver Assembly	1

CLASS IV	
WEIGHT CARRYING HITCH CAPACITY	
4,000 LBS. MAXIMUM TRAILER WEIGHT	
400 LBS. MAXIMUM TONGUE WEIGHT	
WEIGHT DISTRIBUTING HITCH CAPACITY	
6,000 LBS. MAXIMUM TRAILER WEIGHT	
600 LBS. MAXIMUM TONGUE WEIGHT	



1. Disconnect the two license plate light wires on the backside of the bumper. Remove the four bumper bracket to frame mounting bolts from each side of vehicle. Save the attachment bolts for later hitch installation. Remove the bumper assembly from vehicle.
2. To make assembly of hitch and vehicle parts easier, you may enlarge the existing holes in vehicle frame to 1/2" diameter.
3. With the bumper assembly laying face down and brackets pointing up, locate the two bolts nearest each end of the bumper which attach the angled brackets to the inside of the bumper. Loosen these two bolts on each side of bumper.
4. Tip the bumper assembly over so that the sheet metal filler panel is up. Locate the one bolt on each end of this panel which attaches to the top of the angled bracket. Loosen these two bolts. The angled bracket can now be pushed outward towards the ends of the bumper. The extra space gained by moving the bumper brackets outward, is taken up when the hitch is installed. See Illustration 2 below.
5. With the help of another person or an installation jack, position the side plate section of the hitch assembly against the outside surface of each vehicle side frame. Slide the bumper assembly back into position on the frame with the angled bumper bracket on the outside of the hitch assembly frame brackets and the straight bumper bracket inside the vehicle frame channel.
6. Bolt both the bumper brackets and hitch assembly to the vehicle frame using the original bolts removed in Step 1.
7. Tighten all the 7/16" bolts to 55 ft. lbs. torque. Failure to tighten bolts as described may result in fastener loss or failure.
8. Reconnect the license plate light wires and check light operation.



For information regarding the installation of this product, go to: www.towingsupport.com
or Email us at: tech@towingsupport.com or Call our Technical Support Team at: 1-800-344-3230

This product complies with regulation V-5, C.S.A Standard D-264 and safety requirements for connecting devices and towing systems of the State of New York