

# INSTALLATION INSTRUCTIONS

Rev. 1

**MODEL NO. 81100      78138**

**APPLICATION:**                      **1995-97 Chevrolet Blazer**  
    **1995-97 GMC Jimmy**  
    **1996-97 Oldsmobile Bravada**

**WARNING:** Although this hitch is designed to safely tow its rated load, we recommend that you consult your vehicle owner's manual for possible manufacturer's recommendations or limitations. Trailer brakes are recommended for towing loads in excess of 1500 lbs. Always follow the manufacturer's installation instructions and always install on the specified vehicle. Before installing hitch, check that the attachment points are in good condition.

Failure to follow these guidelines will void warranty. Any modifications to this hitch will void warranty.


**WARNING:** Use only a 5/8" diameter hitch pin with locking device to secure a ball mount in this receiver. Be sure to check the hitch pin and hair pin for positive locking placement before towing trailer.

**NOTE:** Some states require a clear view of license plates. Remove trailer ball and/or ball mount when not in use if it restricts view.


| <b>COMPLETE PARTS LIST</b> |               |                                |                 |
|----------------------------|---------------|--------------------------------|-----------------|
| <i>Item</i>                | <i>Part #</i> | <i>Description</i>             | <i>Quantity</i> |
| 1.                         |               | Receiver Assembly              | 1               |
| 2.                         | 1142-03       | 1/2 Lockwasher                 | 2               |
| 3.                         | 3976-07       | Plate                          | 2               |
| 4.                         | 1828-03       | 1/2-13 Serrated Flange Locknut | 6               |
| 5.                         | 1836-03       | 1/2-13 x 1-1/2 Hex Bolt Gr. 5  | 6               |

| <b>CLASS IV</b>   |
|---|
| <b><u>WEIGHT CARRYING HITCH CAPACITY</u></b>                        |
| 4,000 LBS. MAXIMUM TRAILER WEIGHT<br>400 LBS. MAXIMUM TONGUE WEIGHT |
| <b><u>WEIGHT DISTRIBUTING HITCH CAPACITY</u></b>                    |
| 6,000 LBS. MAXIMUM TRAILER WEIGHT<br>600 LBS. MAXIMUM TONGUE WEIGHT |


**Bumper Bracket**



**Vehicle Side Frame**



1. Position receiver assembly under vehicle so that the frame brackets at the end of the cross tube are resting against the outer surface of the vehicle side frame, just forward of the bumper brackets. There are two small holes and one large hole at this location on each side frame.
2. Attach receiver assembly to vehicle frame at the forward two holes on each side. Do not tighten bolts at this time.
3. Insert the rearmost attachment bolt through the open hole in each hitch frame bracket. The bolt will exit through the large hole in the vehicle frame. Place a 1/2" lockwasher on the bolt and position it in the large hole. It will be acting as a bushing. Place a plate #3 on bolt and secure parts to the frame with a 1/2" serrated flange nut #4. See illustration 2.
4. Tighten all 1/2" bolts to 75 ft. lbs. torque. Failure to tighten bolts as described may result in fastener loss or failure.



For information regarding the installation of this product, go to: [www.towingsupport.com](http://www.towingsupport.com)  
or Email us at: [tech@towingsupport.com](mailto:tech@towingsupport.com) or Call our Technical Support Team at: 1-800-344-3230  
This product complies with regulation V-5, C.S.A Standard D-264 and safety requirements for connecting devices  
and towing systems of the State of New York